



1. screw the s.s fixing rod on to the body
2. install the flexible hose
3. put the rubber gasket onto the fixing rod
4. put the s.s. gasket onto the fixing rod
5. fasten the plastic nut

