


ASSEMBLY INSTRUCTION


Y1259-C14/423 Ran dining chair alu black/rope black/flax beige

Y1259-C14/453 Ran dining chair alu black/rope black/emerald green


Y1259-C14/487 Ran dining chair alu black/rope black/panther black




HW-ST-02-111
(6 x 22)




HW-ST-07-063
(6.5x16x2)




HW-ST-03-010
(6x6)




HW-PL-07-004
(6.5x16x2)




HW-ST-18-001
(4x88)






HW-ST-18-009
(10x76)









Ⓐ x 1
SU-SC-LF-0721



Ⓑ x 1
SU-SC-BF-0359



 <p>① x 4 HW-ST-02-111 (6 x 22)</p>	 <p>② x 4 HW-ST-07-063 (6.5x16x2)</p>	 <p>③ x 4 HW-ST-03-010 (6x6)</p>	 <p>④ x 4 HW-PL-07-004 (6.5x16x2)</p>	 <p>⑤ x 1 HW-ST-18-001 (4x98)</p>	 <p>⑥ x 1 HW-ST-18-009 (10x76)</p>
--	--	---	--	--	--

